


KRUPP

Ersatzteilliste (Bildtafel)
List of spare parts (Plane of project.)

| Benennung | Description | Bildtafel Nr. Plane of projection No. | A-Zu mod. state | FHG |
|-----------|-------------|--|-----------------------|-----|
| Lenkung | Steering | 1 555 560 | B | 077 |
| | | ETL-Nr. 1 291 769 | Blatt Sheet | 1 |

ME = Mengeneinheit / QCD = Quantity Code
 01 - Stück 06 - m³ 17 - cm² 24 - Zoll
 02 - kg 07 - l 18 - dm² 25 - mg
 03 - t 08 - cm 20 - cm³ 26 - 1/1000 Stück
 04 - m 09 - g 22 - Satz
 05 - m² 10 - mm 23 - Paar

| A-Zust. mod.state | Pos. Item | Stücklisten-Nr. Liste of spare parts No. | | Menge Quantity | ME QCD | Benennung | Description | Bemerkung Remark |
|------------------------|--------------|---|-----|-------------------|-----------|--|----------------------------------|---------------------|
| | | Teile-Nr. Part-No. | ETL | | | | | |
| | 002 | 1574558 | | 1.0 | 01 | LENKSAEULE FUER SERVOSTA T II | STEERING PILLAR FOR SERVOSTAT II | |
| | 003 | 0558528 | | 1.0 | 01 | LENKRAD | STEERING WHEEL | |
| | 004 | 0559167 | | 1.0 | 01 | SIGNAL F. LENKUNG | SIGNAL FOR STEERING ASSEMBLY | |
| | 005 | 1680190 | | 4.0 | 01 | SCHRAUBE, 6KT- M_8X20 DIN 9 33 - 10.9 | HEXAGON SCREW | |
| | 007 | 1678283 | | 1.0 | 01 | KNOPF, STEUER- FUER LENKRAD | BUTTON FOR STEERING WHEEL | |
| *** ENDE DER LISTE *** | | | | | | *** END OF THE LIST *** | | |

| | | | | | | | | |
|--|-----------|--|-------------|--|--|------------------------|---------------|---|
|  KRUPP Ersatzteilliste List of spare parts (Plane of project) | Benennung | | Description | | Ersatzteilliste Nr. List of spare parts No. | A-Zu. mod. state | FHG | |
| | LENKUNG | | STEERING | | 1291769-ETL | C | 077 | |
| | | | | | Datum Date | 13.03.86 | Seite Page | 1 |

1551097-11.84