
	Benennung	Description	Bildtafel Nr. Plane of projection No.	A-Zu mod. state	FHG
	Ersatzteilliste (Bildtafel) List of spare parts (Plane of project.)	Pumpe, Ölbehälter, Zubehör	Pump, Oiltank, Accessories	1 555 232	B
			ETL-Nr. 1 673 578	Blatt Sheet	1

ME = Mengeneinheit / QCD = Quantity Code
 01 - Stück 06 - m³ 17 - cm² 24 - Zoll
 02 - kg 07 - l 18 - dm² 25 - mg
 03 - t 08 - cm 20 - cm³ 26 - 1/1000 Stück
 04 - m 09 - g 22 - Satz
 05 - m² 10 - mm 23 - Paar

Ä-Zust. mod.state	Pos. Item	Stücklisten-Nr. Liste of spare parts No.		Menge Quantity	ME QCD	Benennung	Description	Bemerkung Remark
		Teile-Nr. Part-No.	ETL					
C	001	1673579	ETL	1.0	01	PUMPEN- U. OELBEH. - EINBAU	PUMPS-MOUNTING AND OIL-TANK-MOUNTING	
	002	1571704		1.0	01	MANOMETER (VERSCHMUTZUNG SANZEIGE)	MANOMETER (FOULING INDICATOR)	
	003	0553383		3.0	01	MANOMETER, GLYZERIN	GLYCERIN-MANOMETER	
	004	0559912		1.0	01	MANOMETER, GLYZERIN	GLYCERIN-MANOMETER	
	005	1066879		1.0	01	VENTIL, RUECKSCHLAG -	NON-RETURN VALVE	
	007	0550174		2.0	01	VENTIL, RUECKSCHLAG	BACK-PRESSURE VALVE	
	008	0552035		1.0	01	VENTIL, RUECKSCHLAG	BACK-PRESSURE VALVE	
	011	1201396		6.0	01	STUTZEN, MESZ-	CONNECTING ADAPTER	
	029	1575139		5.0	01	VERSCHRAUBUNG, MANOMETER-ANSCHLUSS-	PRESSURE-GAUGE-CONNECTION SCREW COUPLING	
	034	1205002		3.0	01	SCHLAUCH, HOCHDRUCK	HIGH-PRESSURE HOSE	
	035	0559316		1.0	01	LEITUNG, SCHLAUCH- 2SN_40NN1100P DIN 20066	HOSE ASSEMBLY	
	036	1677771		1.0	01	LEITUNG, SCHLAUCH- 4SP_20PP1800P DIN 20066	HOSE ASSEMBLY	
	037	1204799		1.0	01	LEITUNG, SCHLAUCH- 4SP_20PP2500P DIN 20066	HOSE ASSEMBLY	
	038	1575506		1.0	01	LEITUNG, SCHLAUCH- 2SN_40NN650P DIN 20066	HOSE ASSEMBLY	
	039	0559310		1.0	01	LEITUNG, SCHLAUCH- 4SP_16PP2500P DIN 20066	HOSE ASSEMBLY	
	040	1571114		1.0	01	LEITUNG, SCHLAUCH- 2SN_16NN800P DIN 20066	HOSE ASSEMBLY	
	041	1677857		1.0	01	LEITUNG, SCHLAUCH- 2SN_25NN900P DIN 20066	HOSE ASSEMBLY	
	047	1677100		2.0	01	ANSCHLUSS, FLANSCH-	FLANGED JOINT	
	048	1575183		1.0	01	ANSCHLUSS, FLANSCH-	FLANGED JOINT	
	065	1570178		1.0	01	VENTIL, DRUCKBEGR.-	RELIEF VALVE	
	067	0557814		1.0	01	VENTIL, RUECKSCHLAG -	NON-RETURN VALVE	
						*** ENDE DER LISTE ***	*** END OF THE LIST ***	

 KRUPP Ersatzteilliste List of spare parts (Plane of project)	Benennung	Description	Ersatzteilliste Nr. List of spare parts No.	Ä-Zu. mod. state	FHG
	PUMPE, OELBEH., ZUB.	PUMP, OIL-TANK, ACCESSORIES	1673578-ETL	C	786
			Datum 13.03.86 Date	Seite 1 Page	