

KRUPP

Benennung
Einschub 5. A Oberwagen

Description
Slide-in unit 5A turntable


Bildtafel Nr. Plane of projection No.	A-Zu mod. state	FHG
1 555 582		807
ETL-Nr. 1 676 364	Blatt Sheet	1

Ersatzteilliste (Bildtafel)
List of spare parts (Plane of project.)

ME - Mengeneinheit / QCD - Quantity Code

01 - Stück 06 - m³ 17 - cm² 24 - Zoll
 02 - kg 07 - l 18 - dm² 25 - mg
 03 - t 08 - cm 20 - cm³ 26 - 1/1000 Stück
 04 - m 09 - g 22 - Satz
 05 - m² 10 - mm 23 - Paar

Ä-Zust. mod.state	Pos. Item	Stücklisten-Nr. Liste of spare parts No.		Menge Quantity	ME QCD	Benennung	Description	Bemerkung Remark
		Teile-Nr. Part-No.	ETL					
	004	1669354		1.0	01	E-TEILE STECKVERBINDU NG	ELECTR. PARTS, PLUG CONNECTION	
	004.01	1576389		1.0	01	STECKER	PLUG	
	004.02	1576390		1.0	01	KODIERSCHEIBENAST		
	004.03	1576391		1.0	01	STECKER	PLUG	
	005	1677744		4.0	01	TASTER, DRUCK-	PUSH-BUTTON	
	006	1574266		2.0	01	SCHALTER, KIPP-	TOGGLE SWITCH	
	008	0553027		1.0	01	KAPPE, ABDECK-	PROTECTIVE COVER	
	014	0554121		1.0	01	SCHALTER, DRUCKKNF-	PUSH-BUTTON SWITCH	
	015	1677741		2.0	01	GLEICHRICHTER	BELLMOUTH	
	020	1680204		6.0	01	HUELSE, STECK-	RECEPTACLE	
	021	1685569		11.0	01	HUELSE, STECK-	RECEPTACLE	
	023	1680203		6.0	01	HUELSE, ADEREND-	END-SLEEVE	
*** ENDE DER LISTE ***						*** END OF THE LIST ***		

 KRUPP Ersatzteilliste List of spare parts (Plane of project)	Benennung		Description		Ersatzteilliste Nr. List of spare parts No.	Ä-Zu. mod. state	FHG
	EINSCHUB 5A		OBERWAGEN		SLIDE-IN UNIT 5A, TURNTABLE		1676364-ETL
					Datum Date	Seite Page	
					13.03.86	1	