
	Benennung	Description	Bildtafel Nr. Plane of projection No.	A-Zu mod. state	FHG
	Ersatzteilliste (Bildtafel) List of spare parts (Plane of project.)	Einschub 5.1A Oberwagen	Slide-in unit 5.1A turntable	1 555 582	
			ETL-Nr. 1 738 827	Blatt Sheet	1

ME = Mengeneinheit / QCD = Quantity Code
 01 - Stück 06 - m³ 17 - cm² 24 - Zoll
 02 - kg 07 - l 18 - dm² 25 - mg
 03 - t 08 - cm 20 - cm³ 26 - 1/1000 Stück
 04 - m 09 - g 22 - Satz
 05 - m² 10 - mm 23 - Paar

A-Zust. mod.state	Pos. Item	Stücklisten-Nr. Liste of spare parts No.		Menge Quantity	ME QCD	Benennung	Description	Bemerkung Remark
		Teile-Nr. Part-No.	ETL					
B	001	1676364	ETL	1.0	01	EINSCHUB 5A OBERWAGEN	SLIDE-IN UNIT 5A, TURNTABLE	
	002	0557971		1.0	01	SCHALTER, MOTOR-	MOTOR CONTROLLER	
	003	1576401		2.0	01	HUELSE, STECK- 245 -MS-PVC	_9,5X6 DIN 46 RECEPTACLE	
*** ENDE DER LISTE ***						*** END OF THE LIST ***		

 KRUPP Ersatzteilliste List of spare parts (Plane of project)	Benennung		Description		Ersatzteilliste Nr. List of spare parts No.	A-Zu. mod. state	FHG	
	EINSCHUB 5.1A OBERWAGEN		SLIDE-IN UNIT 5.1A, TURNTABLE		1738827-ETL	A	807	
					Datum Date	13.03.86	Seite Page	1

1551087-11.84