


FUEL TANK INSTALLATION RH



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
51+	6-880-990274	1	Fuel Tank Sub Assy RH	63	95265	1	Padlock
52	6-184-991562	1	Fuel Tank Bracket Weld				
53	2-184-995029	1	Fuel Tank Bracket				
54	7-126-241253	4	Hex Head Screw M16 x 25mm Long				
55	7-951-240210	4	Spring Washer M16				
56	2-850-995000	2	Strap Weld				
57	7-661-190003	2	Hex Nut M10				
58	7-951-190210	2	Spring Washer Dia.10				
59	6-949-995003	2	Tapered Washer				
61	4-814-990018	2	Protection Pad				
62	4-814-990019	4	Protection Pad				

+ See further breakdown in this group

6-880-990277  
Issue No 02