


BALLAST REMOVAL SOLENOID VALVE ASSEMBLY



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
1	7-443-991181	4	Adaptor $\frac{3}{8}$ " BSP				
2	7067217	4	Washer Spring M5				
3	7097615	4	Socket Head Cap Screw M5 x 50 Long				
4	7355204	4	Seal $\frac{3}{8}$ " BSP				
5	8592964	1	Solenoid Subplate				
6 +	8867492	1	Valve Control				
7	7097613	4	Screw Socket Head Cap M5 x 335 Long				

+ See further breakdown in this group