


OUTRIGGER CONTROL VALVE INSTALLATION



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
1 +	6-926-990403	1	Solenoid Valve Sub Assembly				
2 +	6-926-990404	1	Solenoid Valve Sub Assembly				
3	7-951-190210	8	Lockwasher 10mm				
4	7-661-190003	8	Nut Hex M10 x 1.5				
5 +	6-926-990405	1	Solenoid and Reducing Valve Sub Assembly				
6	7-661-170003	2	Nut Hex M8				
7	7-951-170210	2	Lockwasher 8mm				

+ See further breakdown in this group

6-926-990417  
Issue No. 00